

Thule Step - Repair Kit Rivet for Single ALU (Manual 550 ALU & 12V 460-550)

> Instructions



Thule Step - Rivet Repair Kit for Single ALU

Prod.nr. 1500601153
2S903-04

(Manual 550 ALU and 12V 460-550)



NL INHOUD REPAIR KIT

- a. Schroefbout DIN 933 - M6 x 25 2
- b. Rivet met gat 2
- c. Nylon sluitring Ø18/11 x 1,2 4
- d. Kunststoflager Ø13/11 x 8,5 2
- e. RVS sluitring DIN 9021 - M6 2
- f. Borgmoer DIN 985 - M6 2
- g. Schroefbout DIN 931 - M10x40 2
- h. Kunststoflager Ø13/10 x 8..... 4
- i. Borgmoer DIN 985 - M10 2

FR CONTENU DU KIT DE REPARATION

- a. Boulon DIN 933 - M6 x 25 2
- b. Rivet avec trou 2
- c. Rondelle en nylon Ø18/11 x 1,2 4
- d. Coussinet Ø13/11 x 8,5 2
- e. Rondelle en inox DIN 9021 - M6 2
- f. Ecrou DIN 985 - M6 2
- g. Boulon DIN 931 - M10x40..... 2
- h. Coussinet Ø13/10 x 8..... 4
- i. Ecrou DIN 985 - M10..... 2

D INHALT REPARATUR KIT

- a. Bolzen DIN 933 - M6 x 25 2
- b. Nieten mit Loch 2
- c. Unterlegscheiben Ø18/11 x 1,2 (Nylon) 4
- d. Kunststofflager Ø13/11 x 8,5 2
- e. Unterlegscheiben DIN 9021 - M6 (RFS) 2
- f. Muttern DIN 985 - M6 2
- g. Bolzen DIN 931 - M10x40..... 2
- h. Kunststofflager Ø13/10 x 8..... 4
- i. Muttern DIN 985 - M10 2

EN CONTENTS REPAIR KIT

- a. Bolt DIN 933 - M6 x 25 (a)..... 2
- b. Rivet with hole (b)..... 2
- c. Washer Ø18/11 x 1,2 (nylon) (c)..... 4
- d. Nylon bearing Ø13/11 x 8,5 (d)..... 2
- e. Washer DIN 9021 - M6 (stainless steel) (e)..... 2
- f. Security nut DIN 985 - M6 (f) 2
- g. Bolt DIN 931 - M10x40..... 2
- h. Nylon bearing Ø13/10 x 8..... 4
- i. Security nut DIN 985 - M10 2

